

SECTION 6E

AUTOMATIC TRANSMISSION

The service procedures for the 1964 Corvair automatic transmission are the same as 1961 except for the addition of service operations for the planet assembly.

In addition, further information concerning front pump testing is being added to the Trouble Shooting procedures carried in the 1961 Corvair Manual.

SERVICE OPERATIONS

Planet Carrier Assembly

Removal and Inspection

1. Remove the planet carrier assembly as outlined in the 1961 Corvair Shop Manual.
2. Wash planet carrier in cleaning solvent, blow out all oil passages and air dry.

CAUTION: Do not use rags to dry parts.

3. Inspect planet pinions for nicks or other tooth damage.




Fig. 6E-1—Checking Planet Gear End Clearance

4. Check end clearance of planet gears. This clearance should be .005"-.035" (fig. 6E-1).
5. Check input sun gear for tooth damage, also check input sun gear thrust washer for damage.
6. Inspect planet carrier splines for nicks or damage. Also, check pinion shaft ends for proper staking.

Repairs

If during inspection, the planet pinions, pinion needle bearings, pinion thrust washers, input sun gear,

and/or input sun gear thrust washer should show excessive wear or damage, they should be replaced using the following procedure.

Refer to Figure 6E-2

1. Place the planet carrier assembly in a fixture or vise with the splined end facing down.
2. Starting with a short planet pinion, and using a soft steel drive, drive on the upper end of the pinion shaft until the pinion shaft is driven beyond the staked positions and pressed fit area of the carrier housing. Feed J-9560-1 into the short planet pinion from the upper end (fig. 6E-3), pushing the planet pinion shaft ahead until the tool is centered in the pinion.
3. Remove the short planet pinion and lower pinion thrust washer from the assembly. Complete removal of pinion shaft from assembly.
4. Remove J-9560-1, needle bearings and needle bearing washers (2) from the short planet pinion.

CAUTION: Use care so as not to lose any of the planet pinion needle bearings. Twenty needle bearings (long) are used with the short planet pinion. Forty needle bearings (short) are used with the long planet pinion, twenty on each end with a spacer in the middle.

5. Remove and disassemble the remaining short planet pinions.
6. Remove the input sun gear and input sun gear thrust washer.
7. By following the procedure as outlined in Steps 2, 3, and 4, remove the long planet pinions and upper and lower pinion thrust washers.
8. Wash all parts in cleaning solvent and air dry.
9. Recheck the planet pinion gears and input sun gear for nicks or other tooth damage, also check the planet pinion thrust washers and input sun gear thrust washer. Replace worn or damaged parts.




Fig. 6E-2—Planet Carrier Assembly—Exploded View

- | | |
|--------------------------------|----------------------------------|
| 1. Lower Pinion Thrust Washers | 7. Long Planet Pinion Gear |
| 2. Pinion Shafts | 8. Upper Pinion Thrust Washers |
| 3. Needle Bearings—Short | 9. Input Sun Gear |
| 4. Needle Bearing Washers | 10. Input Sun Gear Thrust Washer |
| 5. Short Planet Pinion Gear | 11. Planet Carrier |
| 6. Needle Bearings—Long | |




Fig. 6E-3—Removing Planet Pinion

10. Inspect the planet pinion needle bearings closely and, if excessive wear is evident, all the needle bearings must be replaced. Also, inspect pinion shafts closely and, if worn, replace the worn shafts.
11. Using J-9560-2 assemble needle bearing spacer and short needle bearings (20 in each end) in one of the long planet pinions. Use petroleum jelly to aid in assembling and holding the needle bearings in position. Place needle bearing washer at each end of planet pinion.

12. Reverse position of carrier in fixture.
13. Position the long planet pinion with J-9560-2 centered in the pinion assembly and with thrust washers at each end, in the planet carrier. Oil grooves on thrust washers must be towards gears. Align thrust washers with the carrier holes.

NOTE: The long planet pinions are located opposite the closed portions of the carrier, while the short planet pinions are located in the openings.

14. Select the proper pinion shaft, lubricate the shaft and install it by tapping with a hammer (fig. 6E-4), pushing the assembling tool ahead of it.




Fig. 6E-4—Installing Planet Pinion

15. With a brass or soft steel drift, drive the pinion shaft until the lower end engages the staked positions on the lower face of the carrier.
16. Assemble and install the remaining long planet pinions.
17. Install the input sun gear thrust washer and input sun gear.
18. Following the same general procedure as outlined in Steps 11-15, assemble and install the short planet pinions in the planet carrier. Each short pinion uses 20 long needle bearings with a needle bearing washer on each end.

NOTE: Paired thrust washers are used on the pinion thrust surface toward the flanged side of the planet carrier, from the short to the long planet pinions while the opposite thrust surface has an individual thrust washer.

19. Check end clearance of planet gears. This clearance should be .005"-.035" (fig. 6E-1).
20. Using a chisel or center punch, restake the pinion shaft at four places on both ends of planet carrier (fig. 6E-5).

Corvair Powerglide—Exploded View

Figure 6E-29 on page 6E-15 of the 1961 Corvair and Corvair 95 Shop Manual shows an incorrect posi-




Fig. 6E-5—Staking Planet Pinion Shaft

tion for the front pump gasket. The corrected figure as shown in Figure 6E-6 illustrates the gasket between the front pump body and the transmission case.

TROUBLE SHOOTING

While trouble shooting information remains the same for 1964 as covered in the 1961 Corvair Shop Manual, the following will aid in more accurately interpreting the hydraulic pressure test procedures.

Front Pump Check

Front pump pressures as measured on the front pump pressure gauge are actual pump pressures, not mainline pressures, and **must** be obtained with the engine speed at idle (16" Hg.).

Low Band Adjustment

Also since no periodic adjustment of the low band is recommended; access to the adjusting screw, from inside the vehicle via the parcel compartment area, has been **eliminated**.

Downshift Timing Valve

A downshift timing valve is now used in the transmission assembly on all engine models. The use of this valve is to improve the quality of closed throttle downshifts.

FRONT PUMP PRESSURES (PSI)

Condition	Range Selector Position			
	R	N	D	L
At idle (16" Hg)	104-122	52-64	52-64	94-105
At idle, with vacuum hose disconnected at balance tube	184-200	94-105	94-105	94-105

THROTTLE VALVE (TV) PRESSURES (PSI)

Condition	R	N	D	L
Disconnect TV rod at carburetor and vacuum hose at balance tube. Depress accelerator to W.O.T.*	0	0	45-47	94-105

*By disconnecting TV rod at carburetor, engine remains at idle speed throughout test.

**CORVAIR POWERGLIDE
SHIFT POINT—MPH CHART**

AXLE 3.27 3.55

UPSHIFTS

MPH

Minimum Throttle 14-16 12-15

Full Throttle 46-52 42-48

Part Throttle (Detent Touch) 35-44 33-40

DOWNSHIFTS

Closed Throttle 12-15 11-14

Full Throttle 42-48 38-44

Part Throttle (Detent Touch) 24-33 22-30

Manual Low (Inhibited) 56-61 52-57




Fig. 6E-6—Corvair Powerglide—Exploded View

- | | | | |
|---|---|--|--|
| 1. Front Pump Mounting Bolts | 16. Low Band Apply Strut | 29. Transmission Throttle Valve Lever Shaft Seal | 45. Oil Pan |
| 2. Front Pump Cover | 17. Planet Carrier Assembly | 30. Transmission Throttle Valve Lever and Shaft | 46. Oil Pan Attaching Screws |
| 3. Front Pump Seal Ring | 18. Ring Gear | 31. Manual Valve Lever | 47. Oil Pick-up Pipe Attaching Screw |
| 4. Front Pump Shaft Drive Hub and Retaining Rings | 19. Reverse Clutch Plates Retaining Ring | 32. Transmission Throttle Valve Inner Lever | 48. Low Servo Piston Retaining Clip |
| 5. Front Pump Driven Gear | 20. Reverse Clutch Front Reaction Plate (Thick) | 33. Governor Gear Thrust Spacer | 49. Low Servo Piston |
| 6. Front Pump Drive Gear | 21. Reverse Clutch Reaction Plates | 34. Governor Drive Gear | 50. Low Servo Piston Ring |
| 7. Front Pump Body | 22. Reverse Clutch Faced Plates | 35. Turbine Shaft Front Bushing | 51. Low Servo Piston Cushion Spring |
| 8. Front Pump Gasket | 23. Rear Pump and Reverse Piston Assembly | 36. Turbine Shaft | 52. Low Servo Piston Cushion Spring Seat |
| 9. Front Pump Body Bushing | 24. Rear Pump Wear Plate | 37. Turbine Shaft Rear Bushing | 53. Low Servo Piston Shaft |
| 10. Clutch Drum Selective Thrust Washer | 25. Low Band Adjusting Screw and Lock Nut | 38. Converter Assembly | 54. Relief Ball Spring Retainer |
| 11. Front Pump Body Hub Iron Seal Rings | 26. Governor Driven Gear and Retaining Pin | 39. Converter Hub Bushing | 55. Low Servo Piston Return Spring |
| 12. Clutch Drum Assembly | 27. Governor "O" Ring Seal | 40. Rear Pump and Reverse Piston Assembly Attaching Screws | 56. Relief Ball |
| 13. Low Sun Gear-to-Input Sun Gear Thrust Washer | 28. Governor Assembly | 41. Valve Body Assembly | 57. Vacuum Modulator Valve |
| 14. Low Band Reaction Strut | | 42. Oil Pick-up Pipe "O" Ring Seal | 58. Vacuum Modulator Gasket |
| 15. Low Band | | 43. Oil Pick-up Pipe Assembly | 59. Vacuum Modulator |
| | | 44. Oil Pan Gasket | 60. Front Pump Shaft |
| | | | 61. Downshift Timing Valve |