

## **NEW FORCED AIR HEATER**

Provides crossflow heating from four outlets—one large low outlet in front of vehicle, one large outlet under rearmost seat, and two defroster outlets. Utilizes heat from engine. Hot air from around cylinder banks is blended with cooler air, then distributed throughout vehicle by three-speed heater blower.

**Forced Air Heater**—985088 or FOA 113.