

Corvair owners, as well as those with other classic automobiles, have replaced every lamp imaginable on their cars over 30-plus years of multi-owner history. Unfortunately, sometimes anything that would fit has been called into play. Although this will work, dashes will not be as bright as when new, turn signals may be mismatched, stop- and turn-lamps may be wrong numbers. Since locating Sylvania's complete list for year-specific Corvairs, I have kept a copy in my "Vair" folder; I thought you might like to do the same. (The year-by-year data may be found on Sylvania's web site.) By the way, the original instrument panel lamp makes the speedo and fuel gauge cluster "glow" at night. Common replacements are very dim. Bright motoring . . .

From Sylvania: "The applications presented in this replacement guide have been compiled using the best information available from the vehicle manufacturers at the time of your search. This guide is intended for general information purposes only, not to be construed as any type of warrantee as to any particular application. For specific applications the vehicle owner's manual should be consulted." **Note:** The "LL" or long-life upgrade lights provide up to twice the life of the standard lamp.

**1960 Chevrolet Corvair**

Low beam headlamp.....	H5006
High beam headlamp.....	H5001
Parking light.....	1034
Front turn signal.....	1034
Rear turn signal.....	1034
Tail light.....	1034
Stop light.....	1034
License plate.....	.67
Back up light.....	1073
Glove box.....	.57
Dome light.....	211-2
Step/Courtesy light.....	.89
Instrument-general.....	53, 57
Automatic transmission indicator.....	53
Directional signal indicator.....	53
Radio dial.....	1891

**1963 Chevrolet Corvair**

Low beam headlamp.....	H5006
High beam headlamp.....	H5001
Parking light.....	1034
Front turn signal.....	1034
Rear turn signal.....	1034
Tail light.....	1034
Stop light.....	1034
License plate.....	.67
Back up light.....	1073
Glove box.....	.57
Map light.....	211-2
Dome light.....	211-2
Step/Courtesy light.....	.89
Trunk/Cargo area.....	.93
Under hood light.....	.93
Instrument-general.....	.57, 53, 57, 89
Brake warning.....	.57
Automatic transmission indicator.....	.53
Clock.....	.57
Directional signal indicator.....	53, 57
Ignition switch.....	1895
Radio dial.....	.57

**1961 Chevrolet Corvair**

Low beam headlamp.....	H5006
High beam headlamp.....	H5001
Parking light.....	1034
Front turn signal.....	1034
Rear turn signal.....	1034
Tail light.....	1034
Stop light.....	1034
License plate.....	.67
Back up light.....	1073
Glove box.....	.57
Dome light.....	211-2
Step/Courtesy light.....	.89
Instrument-general.....	53, 57
Brake warning.....	.53
Automatic transmission indicator.....	.53
Directional signal indicator.....	53, 57
Radio dial.....	.57

**1964 Chevrolet Corvair**

Low beam headlamp.....	H5006
High beam headlamp.....	H5001
Parking light.....	1157, 1157LL
Front turn signal.....	1157, 1157LL
Rear turn signal.....	1157, 1157LL
Tail light.....	1157, 1157LL
Stop light.....	1157, 1157LL
License plate.....	1155
Back up light.....	1156, 1156LL
Ash tray.....	1895
Glove box.....	1895
Map light.....	211-2
Dome light.....	211-2
Step/Courtesy light.....	.631
Trunk/Cargo area.....	1003, 1003LL
Under hood light.....	.93
Instrument-general.....	1816, 1895, 57
Brake warning.....	.57
Automatic transmission indicator.....	1445
Clock.....	1895
Directional signal indicator.....	1895
Ignition switch.....	1895
Radio dial.....	1893

**1962 Chevrolet Corvair**

Low beam headlamp.....	H5006
High beam headlamp.....	H5001
Parking light.....	1034
Front turn signal.....	1034
Rear turn signal.....	1034
Tail light.....	1034
Stop light.....	1034
License plate.....	.67
Back up light.....	1073
Glove box.....	.57
Map light.....	211-2
Dome light.....	.90
Step/Courtesy light.....	.89
Trunk/Cargo area.....	.93
Under hood light.....	.93
Instrument-general.....	1816, 57, 53, 57
Brake warning.....	.57
Automatic transmission indicator.....	.53
Clock.....	.57
Directional signal indicator.....	.53, 57
Ignition switch.....	1895
Radio dial.....	.57

**1965 & 1966 Chevrolet Corvairs**

Low beam headlamp.....	H5006
High beam headlamp.....	H5001
Parking light.....	1157, 1157LL
Front turn signal.....	1157, 1157LL
Rear turn signal.....	1157, 1157LL
Tail light.....	1157, 1157LL
Stop light.....	1157, 1157LL
License plate.....	1155
Back up light.....	1156, 1156LL
Glove box.....	1895
Map light.....	211-2
Dome light.....	211-2
Step/Courtesy light.....	.631
Trunk/Cargo area.....	1003, 1003LL
Under hood light.....	.93
Instrument-general.....	1445, 1895, 57
Brake warning.....	.57
Automatic transmission indicator.....	1445
Clock.....	.631
Directional signal indicator.....	1445
Ignition switch.....	1895
Radio dial.....	1893