

985078 LEVEL PLATFORM INSTRUCTION SHEET

1244-54 MODELS



- STEP 1 PURCHASE LOCALLY ENOUGH 3/4 INCH (5-PLY EXTERIOR GRADE "AB") PLYWOOD TO MAKE (3) EQUAL PARTS,
- STEP 2 CUT (3) EQUAL PARTS OF PLYWOOD TO DIMENSION SHOWN. SEE FIG. 1. $\dot{}$
- STEP 3 CUT GROOVE IN ALL (3) PARTS ON "B" SIDE . SEE FIG. 1.
- STEP 4 DRILL (2) HOLES & CUT SLOT IN (1) PART DESIGNATED 'REAR PLATFORM'. SEE VIEW A.
- STEP 5 CUT GROOVES & CHAMFER ALONG EDGES ON OPPOSITE SIDE OF GROOVE ON (1) PART DESIGNATED "CENTER PLATFORM". SEE VIEW B.
- STEP 6 CUT OUT AREA ON REMAINING PART DESIGNATED "FRONT PLATFORM". SEE FIG. 1.



STEP 7

PLATE, LOCATE & DRILL HOLES IN UNDERSIDE OF PLATFORMS.


NOTE Do not drill thru plywood with 3/32 inch drill, SEE FIG. 2.

STEP 8 USING SUPPORTS PROVIDED AS A TEMPLATE, LOCATE & DRILL HOLES IN TOP OF CENTER PLATFORM.

SEE FIG. 2. NOTE Drill thru permissible.

STEP 9 ATTACH REINFORCEMENTS & SUPPORTS TO PLATFORMS WITH SCREWS PROVIDED. SEE FIG. 2.

STEP 10 (ON 1254 MODELS ONLY) LOCATE & DRILL HOLE IN R. H. CORNER OF FRONT PLATFORM. SEE FIG. 2.



SIEP 11 REMOVE & RETAIN SPARE TIRE & ATTACHING PARTS.


STEP 12 ON ALL MODELS, LOCATE CENTER PUNCH & DRILL TWO INSIDE HOLES FOR FRONT & REAR SILL ASSEMBLIES & USING THEM AS A TEMPLATE, LOCATE, CENTER PUNCH & DRILL REMAINING HOLES. SEE FIG. 3

STEP 13 LOCATE, CENTER PUNCH & DRILL FORWARD HOLES IN SIDE SILL ASSEMBLIES & USING THEM AS A

TEMPLATE LOCATE, CENTER PUNCH & DRILL REMAINING HOLES. SEE FIG. 3.

STEP 14 INSTALL ALL SILL ASSEMBLIES WITH ATTACH-ING PARTS PROVIDED. SEE FIG. 3.

STEP 15 ON 1254 MODELS ONLY, REMOVE EXISTING SCREWS ON R.H. SIDE PANEL & INSTALL BRACKETS PROVIDED WITH EXISTING SCREWS. SEE FIG. 3 & VIEW C.



STEP 16 REINSTALL SPARE TIRE.

\$16P 17 INSTALL PLATFORMS & SECURE WITH ATTACHING PARTS PROVIDED. SEE FIG. 4.

STEP 18 TO REMOVE PLATFORMS, REMOVE SCREWS & START BY LIFTING REAR PLATFORM, USING ACCESS HOLE ON R. H. SIDE, SEE FIG. 4.