

988346 DOME LAMP INSTRUCTION SHEET

R-1205 & 1206




FIG. 1 REAR DOOR JAMB SWITCH




FIG. 2 WIRE ASSY. CONNECTION TO LAMP ASSY.




FIG. 3 RETAINER & LAMP ASSY.

STEP 1 LOCATE, CENTER PUNCH & DRILL HOLE IN L. H. REAR DOOR HINGE PILLAR REINFORCEMENT. SEE FIG. 1. (REMOVE L. H. REAR TRIM PANEL FIRST, IF VEHICLE IS MODEL 1206).

STEP 2 PUSH BARE END OF WIRE ASSY. THRU GROMMET & SLIDE GROMMET ALONG WIRE TO A POINT APPROXIMATELY (12) INCHES FROM FUSE HOLDER. THREAD BARE END OF WIRE THRU DRILLED HOLE, FROM UNDER REINFORCEMENT, THEN CLIP WIRE TO PILLAR & ROUTE TO FRONT OF REAR ROOF BOW. SEE FIG. 1.

STEP 3 CRIMP & SOLDER BARE END OF WIRE TO CLIP. SEE VIEW A. REMOVE LENS FROM LAMP ASSY. & INSERT CLIP INTO LAMP BASE THEN INSTALL BULB & REPLACE LENS. SEE FIG. 2.

STEP 4 DRILL HOLES THRU EXISTING DIMPLES IN R. H. FRONT LOAD & L. H. REAR DOOR HINGE PILLARS. SEE FIG. 1 & 4.

STEP 5 POSITION RETAINER ON CENTER OF REAR ROOF BOW & USE IT AS A TEMPLATE TO DRILL HOLES. SEE FIG. 3.

STEP 6 PASS LAMP ASSY. THRU RETAINER & ATTACH RETAINER TO BOW WITH SCREWS PROVIDED. SEE FIG. 3.

STEP 7 DRAW LAMP ASSY. UP TO RETAINER BY PULLING UP ALL LEADS THEN PRESS LAMP ASSY. TO RETAINER UNTIL PRONGS SNAP INTO PLACE. SEE FIG. 3.




FIG. 4 LOAD DOOR JAMB SWITCH




FIG. 5 REGULATOR CONNECTION

STEP 8 PUSH GRAY WIRE OVER FORWARD FLANGE OF ROOF BOW & ROUTE BEHIND R. H. SIDE INNER TRIM PANEL INTO R. H. FRONT LOAD DOOR HINGE PILLAR. SEE FIG. 4.

STEP 9 PUSH BROWN & BLACK WIRES OVER FORWARD FLANGE OF ROOF BOW. ROUTE BROWN WIRE ALONGSIDE BLACK WIRE TO DRILLED HOLE IN REAR DOOR PILLAR. SEE FIG. 4.

STEP 10 PULL TERMINALS OF BROWN & GRAY WIRES OUT THRU DRILLED HOLES. INSERT THEM INTO METAL CONNECTORS ON END OF JAMB SWITCHES & PUSH SWITCHES INTO PLACE. SEE FIG. 1 & 4.

STEP 11 ROUTE TERMINAL END OF WIRE ASSY. TO FRONT OF REGULATOR, CLIP FUSE HOLDER TO HINGE PILLAR & CONNECT WIRE TO BATTERY TERMINAL ON REGULATOR. SEE FIG. 5 & VIEW B.

STEP 12 INSERT GROMMET, PLACED ON WIRE ASSY. IN STEP 2, INTO DRILLED HOLE IN REAR PILLAR REINFORCEMENT. REPLACE L. H. REAR TRIM PANEL IF REMOVED IN STEP 1.