

988476 COURTESY LAMP INSTRUCTION SHEET

500 & R-10 SERIES








FIG. 1 LAMP ASSY.

500 SERIES

- STEP 1** LOCATE & CUT SLOT ON BACK WALL OF INSTRUMENT PANEL COMPARTMENT & INSTALL CLIP THRU SLOT. SEE VIEW B.
- STEP 2** INSTALL CLIP ON TOP EDGE OF R. H. KICK PANEL TO RETAIN WIRE BEHIND KICK PANEL. SEE FIG. 1.
- STEP 3** PLACE LAMP WITH WHITE WIRE IN ITS APPROXIMATE INSTALLED POSITION & ROUTE LAMP WITH BLACK LEAD THRU EXISTING & PROVIDED CLIPS TO R. H. SIDE OF VEHICLE. SEE FIG. 1.
- STEP 4** PLACE LAMP ASSEMBLIES ON INNER SCREWS THAT RETAIN VENT CONTROLS & ATTACH WITH PROVIDED WASHERS & NUTS. SEE VIEW C.

- STEP 5** DRILL HOLES THRU EXISTING DIMPLES IN EACH FRONT DOOR HINGE PILLAR. SEE VIEW A.
- STEP 6** TAPE JUMPER WIRE & CONNECTOR TO TERMINAL WIRE & ROUTE THRU CLIPS ON KICK PANEL & DRILLED HOLE IN PILLAR. THEN INSERT TERMINAL END INTO JAMB SWITCH & PRESS JAMB SWITCH INTO POSITION. SEE FIG. 1 & VIEW A.
- STEP 7** ATTACH CONNECTOR TO JUNCTION BLOCK. ATTACHMENT IS TYPICAL OF FIG. 8 OR 9 EXCEPT FOR POSITION OF JUNCTION BLOCK. REFER TO STEP 10 a FOR DESCRIPTION.



R-10 SERIES

STEP 1a REMOVE BULB & SOCKET FROM EACH SUPPORT & ALTER SUPPORT AS SHOWN. RE-ASSEMBLE SOCKETS, SUPPORTS & BULBS. SEE FIG. 2. **NOTE** If heater exists, do not alter support for R. H. side.

STEP 2a TAPE JUMPER WIRE & CONNECTOR TO TERMINAL WIRE. SEE FIG. 2.




STEP 3a DRILL HOLE THRU EXISTING DIMPLE IN EACH FRONT SIDE DOOR HINGE PILLAR. SEE FIG. 3.

STEP 4a ROUTE TERMINAL WIRE (WHITE) UNDER INSTRUMENT PANEL & OUT THRU DRILLED HOLE IN L. H. SIDE DOOR HINGE PILLAR. INSERT TERMINAL INTO JAMB SWITCH. SEE FIG. 3.

STEP 5a HOLDING JAMB SWITCH SO THAT TERMINAL IS TOWARD CENTER OF CAR, PRESS INTO POSITION. SEE FIG. 3.

STEP 6a REMOVE EXISTING R. H. VENT CONTROL BRACKET. PLACE LAMP SUPPORT ON OUTBOARD SIDE & WASHER ON INBOARD SIDE BETWEEN BRACKET & INSTRUMENT PANEL & RE-ATTACH VENT CONTROL BRACKET. **NOTE** If heater exists, place lamp support on inboard side & washer on outboard side between bracket & instrument panel & re-attach vent control bracket. See Fig. 4.

STEP 7a PLACE CLIP ON L. H. REINFORCEMENT EXTENSION & ROUTE WIRES THRU CLIP LOOP & TAPE ANY EXCESS WHITE WIRE. SEE FIG. 5.



STEP 8a ROUTE LONG ORANGE WIRE UNDER INSTRUMENT PANEL, THRU EXISTING CLIP ON INSTRUMENT CLUSTER, & OVER INSTRUMENT PANEL COMPARTMENT TO R. H. PILLAR. SEE FIG. 6.

STEP 9a COMPLETE R. H. SIDE ASSEMBLY IN SAME MANNER AS STEPS 4a, 5a, 6a & 7a. **NOTE** Terminal wire is black on R. H. side.

STEP 10a FOR VEHICLES WITHOUT AN INSTRUMENT PAN-

EL COMPARTMENT LAMP, PRESS FUSE CLIP ASSY. INTO JUNCTION BLOCK UNTIL LOCKED IN PLACE, THEN INSERT FUSE & ATTACH CONNECTOR. SEE FIG. 7.

STEP 11a FOR VEHICLES WITH AN INSTRUMENT PANEL COMPARTMENT LAMP: PLUG CONNECTOR INTO EXISTING JUMPER WIRE ON COMPARTMENT LIGHT SWITCH WIRE ASSY., & DISCARD FUSE & FUSE CLIP ASSY.

STEP 12a LOOP & TAPE ANY SURPLUS OF WIRE TO PREVENT RATTLING. SEE FIG. 6.